
Installation Instruction – ELANA HD

Model: 2" Round / Square / Multi-Light Recessed Downlight

Installation Statement


1. Read the instruction manual carefully before installation and follow the instructions for operation.
2. Installation must be performed by a qualified electrician. To prevent electric shock, ensure the power supply is switched off before installation or maintenance.
3. For indoor use only. Not suitable for damp locations.
4. The luminaire can be recessed into the ceiling. Do not cover the top of the luminaire with thermal insulation or combustible materials to avoid fire hazards.
5. Do not mount the luminaire on unstable or fragile skylights to prevent it from falling.
6. The light source of this luminaire is non-replaceable. When the light source reaches its end of life, the entire luminaire shall be replaced.
7. Keep this instruction manual properly for future reference.

Luminaire Installation (Square/Multi-head: same installation as Round)



WAC Group retains the right to modify the design of our products at any time as part of the company's continuous improvement program.

Angle Adjustment and Accessories:



*If the luminaire driver is supplied with lead wires and the connection leads need to be connected to an independent terminal block (refer to Fig.④ for the wiring diagram; the terminal block is not included with this luminaire), the dimensions of each terminal block shall be no less than 10 × 20 × 25 mm.

*Luminaires without built-in electrical components are provided with red and black lead wires and must not be directly connected to a 220V AC power supply. Any electrical components supplied by the customer must be compatible with the light source.

WAC Group retains the right to modify the design of our products at any time as part of the company's continuous improvement program.


Installation Instruction – ELANA HD

Model: 3" Round / Square / Multi-Light Recessed Downlight

Installation Statement


1. Read the instruction manual carefully before installation and follow the instructions for operation.
2. Installation must be performed by a qualified electrician. To prevent electric shock, ensure the power supply is switched off before installation or maintenance.
3. For indoor use only. Not suitable for damp locations.
4. The luminaire can be recessed into the ceiling. Do not cover the top of the luminaire with thermal insulation or combustible materials to avoid fire hazards.
5. Do not mount the luminaire on unstable or fragile skylights to prevent it from falling.
6. The light source of this luminaire is non-replaceable. When the light source reaches its end of life, the entire luminaire shall be replaced.
7. Keep this instruction manual properly for future reference.

Luminaire Installation (Square/Multi-head: same installation as Round)



WAC Group retains the right to modify the design of our products at any time as part of the company's continuous improvement program.

Angle Adjustment and Accessories:



*If the luminaire driver is supplied with lead wires and the connection leads need to be connected to an independent terminal block (refer to Fig.④ for the wiring diagram; the terminal block is not included with this luminaire), the dimensions of each terminal block shall be no less than 10 × 20 × 25 mm.

*Luminaires without built-in electrical components are provided with red and black lead wires and must not be directly connected to a 220V AC power supply. Any electrical components supplied by the customer must be compatible with the light source.

WAC Group retains the right to modify the design of our products at any time as part of the company's continuous improvement program.