


## Installation Precautions:


1. Please read through the Instructions before installation.
2. The product should be installed by a professional electrician; Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock
3. Suitable for indoor installation and use (not suitable for damp environments).
4. The lighting fixtures cannot be directly connected to the mains 220V and need to be used together with the electrical appliances. The dimming system used must be tested for compatibility with the electrical appliances in advance.
5. The light source of this fixture is non-replaceable, and once it needs to be replaced (such as at the end of the fixture's lifespan), the entire fixture should be replaced
6. Please keep this Instruction properly for future reference.



## Lamp parameters and electrical selection:


Model	Input	Electrical equipment
ASR45FLD01-M	Constant current 350mA Max, 3V	Used with WAC AMTB power splitter
ASR46FLD03-M ASR46WLD03-M	Constant current 1000 mA Max, 3V	
ASR47FLD05-M	Constant current 400 mA Max, 12V	
ASR45FLD01-N	Constant current 350 mA Max, 3V	Customers can choose and purchase on their own
ASR46FLD03-N ASR46WLD03-N	Constant current 1000 mA Max, 3V	
ASR47FLD05-N	Constant current 400 mA Max, 12V	

## Light Installation and Wiring:



### Installation Precautions:


1. Please read through the Instructions before installation.
2. The product should be installed by a professional electrician; Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock
3. Suitable for indoor installation and use (not suitable for damp environments).
4. The lighting fixtures cannot be directly connected to the mains 220V and need to be used together with the electrical appliances. The dimming system used must be tested for compatibility with the electrical appliances in advance.
5. The light source of this fixture is non-replaceable, and once it needs to be replaced (such as at the end of the fixture's lifespan), the entire fixture should be replaced
6. Please keep this Instruction properly for future reference.



### Lamp parameters and electrical selection:


Model	Input	Electrical equipment
AME45FLD01-M	Constant current 350mA Max, 3V	Used with WAC AMTB power splitter
AME46FLD03-M AME46WLD03-M	Constant current 1000 mA Max, 3V	
AME47FLD05-M	Constant current 400 mA Max, 12V	
AME45FLD01-N	Constant current 350 mA Max, 3V	Customers can choose and purchase on their own
AME46FLD03-N AME46WLD03-N	Constant current 1000 mA Max, 3V	
AME47FLD05-N	Constant current 400 mA Max, 12V	

### Light Installation and Wiring:



## Installation Precautions:


1. Please read through the Instructions before installation.
2. The product should be installed by a professional electrician; Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock
3. Suitable for indoor installation and use (not suitable for damp environments).
4. The lighting fixtures cannot be directly connected to the mains 220V and need to be used together with the electrical appliances. The dimming system used must be tested for compatibility with the electrical appliances in advance.
5. The light source of this fixture is non-replaceable, and once it needs to be replaced (such as at the end of the fixture's lifespan), the entire fixture should be replaced
6. Please keep this Instruction properly for future reference.



## Lamp parameters and electrical selection:


Model	Input	Electrical equipment
ASR48FLD10-M	Constant current 800 mA Max, 12	Used with WAC AMTB power splitter
ASR48SLD10-M		
ASR48FLD10-N	Constant current 800 mA Max, 12V	Customers can choose and purchase on their own
ASR48SLD10-N		

## Light Installation and Wiring:



## Installation Precautions:

1. Please read through the Instructions before installation.
2. The product should be installed by a professional electrician; Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock
3. Suitable for indoor installation and use (not suitable for damp environments).
4. The lighting fixtures cannot be directly connected to the mains 220V and need to be used together with the electrical appliances. The dimming system used must be tested for compatibility with the electrical appliances in advance.
5. The light source of this fixture is non-replaceable, and once it needs to be replaced (such as at the end of the fixture's lifespan), the entire fixture should be replaced
6. Please keep this Instruction properly for future reference.



## Lamp parameters and electrical selection:

Model	Input	Electrical equipment
AME48FLD10-M	Constant current 800 mA Max, 12	Used with WAC AMTB power splitter
AME48SLD10-M		
AME48FLD10-N	Constant current 800 mA Max, 12V	Customers can choose and purchase on their own
AME48SLD10-N		

## Light Installation and Wiring:

